

MAINTENANCE OF FLOOR

After the installation of the floor and of electrical equipment it is important that maintenance of the floor is being performed according to the following instructions:

GENERAL CARE

At least once a year, the floor panels should be removed with the panel lifter. The purpose of this removal is to make it possible to vacuum clean the upper surface of the secondary profiles. If this cleaning is performed, no risk of sounds from particles between the panels and the profiles will exist. It is also important to vacuum clean the concrete floor and the space between the cable ladders in order to avoid additional fire spread if the cables for some reason start to burn.

CLEANING OF FLOOR PANELS

Bergvik Laminate is a low-maintenance floor product. Light dirt is removed by vacuum cleaning or dry-mopping. From time to time, a more careful cleaning is recommended by wet mopping. Please do not use more than necessary amount of water.

A cleaning agent should be added and the water temperature should not be warmer than the hand can accept. Dry afterwards with a cloth. Excessive water amounts will endanger the underlying installations.

SEVERE STAINS ON LAMINATE SURFACE

Severe stains such as petroleum products, paint, glue, or Bitumen can be removed with Acetone, benzene or white spirit applied on a cloth. The laminate has a high resistance against most chemicals. Dry after the treatment of chemicals with a wet cloth (water).

IMPORTANT: Antistatic and semi conductive floor coverings cannot be treated with wax or similar components. The electrical characteristics are changed through this treatment.

ORDERING OF EXTRA FLOOR PANELS

On the CAD drawing submitted by Bergvik, the number of the drawing can be used to trace the type of panels. This is also our internal order number and should be mentioned when ordering replacement.

